



- 1. Drain-pipe
- 2. Rose
- 3. Pannel holder
- 4. Plastic screw pipe
- 5. Screw
- 6. Rubber washer

1. Identify all components are present prior to installation
2. Measure the reserved size
3. Install the pannel holder (3) in the book-position and make in the position of screw hole
4. Drill the hole by using electric drilling machine and put the plastic screw pipe(4) into the hole
5. Put the pannel holder (3) on the hole and plastic screw (5) installed by srew tightly
6. Install the drain pipe(1) into the hole of cistern and screw tightly then install the rose(2), Install the bottom drain pipe(1) into the hole of toilet
7. Please check whether the water leakage after installation is finisher

